

B600 Installation guide

G4-B600 Installation

Three ways to connect

I. Bluetooth connection

Connect the speakers to the powersource via a 12v cable.
Upon successful connection a red light will illuminate within them.
Recommend to install a powerswitch and 10amp fuse between the power and the speakers.
Switch on bluetooth on your phone/tablet and select **G4-B600**. Upon successful connection you will hear the words “G4 connected” and a blue light will illuminate.

II. High level input (Optional)

Connect the speakers via the speaker cables (not included) according to the diagram.

III. Low Level input (Optional)

Connect the speakers to the radio via the RCA cables (not included) according to the diagram

Note:

Connection **I** must always be made for the bluetooth feature.

Main and Slave speakers.

Connections **II** and **III** are optional.

